

# HOW TO MEASURE YOUR RADIATOR

When measuring your radiator, use this guide to make sure you get the correct dimensions

## CORE SIZE

We recommend that you measure the core size. Many vehicle models had multiple core sizes and this is a more accurate way to choose the correct radiator for your application.



## OVERALL RADIATOR SIZE

When getting overall measurements its from "Tank to Tank" and "Band to Band" to get overall thickness measure the tank thickness only. [Please note that when measuring your radiator that you don't include the filler neck or any mounting brackets/ hardware.]



## YOUR RADIATOR'S PARTS

When discussing your radiator, the orientation would be as if you were sitting in your driver's seat looking forward.

