


HOW TO MEASURE YOUR RADIATOR

When measuring your radiator, use this guide to make sure you get the correct dimensions


CORE SIZE

We recommend that you measure the core size. Many vehicle models had multiple core sizes and this is a more accurate way to choose the correct radiator for your application.



OVERALL RADIATOR SIZE

When getting overall measurements its from "Tank to Tank" and "Band to Band" to get overall thickness measure the tank thickness only. [Please note that when measuring your radiator that you don't include the filler neck or any mounting brackets/ hardware.]



YOUR RADIATOR'S PARTS

When discussing your radiator, the orientation would be as if you were sitting in your driver's seat looking out.

