Option: Air Conditioner Relay Diagram

Additional Relay required – not supplied in kit.



Red Wire: To Grey Wire/Temperature Sender

30

87 A

85

86

87

Orange Wire: To A/C Compressor Wire/Trinary Switch

A/C Compressor will send "ground" signal to Temperature Sender to turn fans "on".

Connect Yellow and Grey wires to ground. Connect the Red wire to the sending unit wire of the original fan relay harness. The Orange wire from the A/C relay goes to the +12 volt of the A/C compressor clutch wire. The fan will turn on when the A/C compressor activates.

Vehicle Ground